




MOUNTING INSTRUCTIONS



FOR THE NEXT-DOOR ALUW, ALUR




Prior to the montage check the door opening.




Slip over the jamb auxiliary mounting fixture.

**A**


Put in the jamb into the opening and balance it by the air level. Mark and drill the openings. Put in the plugs and screw them down.




After the screwing check the level by air level. Fill up the space between the jamb and opening with mounting foam.



Put on the door wing.



The setting possibilities of the door wing on the hinge





KRUŽÍK® /

Kroměříž, Veleslavínova 2357, [tel.] 573 336 233, [fax.] 573 343 582
Praha 10 Hostivař, Herbenova 38, [tel.] 267 710 696, [fax.] 267 710 696
г. Мукачево 89622, ООО "Кружик Украина", с. Ивановцы, ул. Мира, 3, [тел] +38-050-523-59-69

18032016

www.kruzik.cz | www.kruzik.com | www.kruzik.com.ua | www.kruzik.eu